

**Link**  
tech

**PREMIUM**  
VIP PRODUCT

# Hello!

**MODEL: LPP-WP16**  
**MagPro WIRELESS POWERBANK**  
**FOR SMARTWATCHES**  
**USER MANUAL**

Please carefully read this Manual before using this Product for the very first time and well keep it for further reference.

Dear Customer

Thank you for choosing LinkTech's products, we appreciate your choice to purchase this product and we're hoping that you'll have a great time using our product.

Please share your experience with our products through LinkTech's customer services center either by phone, Whatsapp or Bip.

Feel free to express your opinions or tell us your suggestions on our channels. LinkTech will happily review all your invaluable feedback in order to improve our products and services.

If you encounter any problem or have difficulties with this product, please refer to the User's Manual, you can contact our customer services if you have any further questions.

LinkTech considers your priceless recognition and support as an encouragement to stay focused on providing high quality products and a motivation to move forward, improve our services and expand our workspace in the future.

LinkTech's Sales Team

## **SUPER FAST Mini POWERBANK**



## Features

- 30W 3-in-1 Portable Power Bank: Compact, pocket-sized design for easy portability.
- Built-in Type-C Cable: Supports dual-way charging (input and output).
- 3W Wireless Charging: Compatible with Apple Watch for seamless wireless charging.

## Specifications

Model	LPP-WP16
Battery Capacity	10000mAh 3.85V/38.5Wh
Weight	~203g
Size	100.3x55.3x29mm
Materials	PC+ABS
Battery Type	Li-ion Polymer Battery
Wireless Charge Output	3W Support Apple Watch
Type-C Input (Port)	5V-3A, 9V-3A, 12V-2.5A, 15V-2A, 20V-1.5A (30W Max)
Type-C Output (Port)	5V-3A, 9V-3A, 12V-2.5A, 15V-2A, 20V-1.5A (30W Max)
Type-C Cable Input	5V-3A, 9V-3A, 12V-2.5A, 15V-2A, 20V-1.5A (30W Max)
Type-C Cable Output	5V-3A, 9V-3A, 12V-2.5A, 15V-2A, 20V-1.5A (30W Max)
Total Output	5V-3A

## Charging Instructions

### Display Status When Charging the Power Bank:

The screen displays the current power level with the number flashing. The number "100" remains steady when fully charged.

### Display Status When Discharging the Power Bank:

The screen displays the current power level. After the battery is fully discharged, there is no output, and the digital display turns off.



**This product is intended for safe use only in non-tropical areas.**

Do not use this product in extreme temperatures, as it may affect its performance and lifespan.

Dismantling, impacting, squeezing, or throwing it into fire is strictly prohibited.

If the product swells significantly, stop using it immediately. Do not place it in high-temperature environments.



## Safety and Usage Guidelines

### Storage and Operating Conditions:

- Do not use or store this product in high-temperature or humid environments, and avoid exposure to direct sunlight.
- Operating temperature range: 0°C to 45°C. (It is recommended not to operate the product in environments above 45°C or below 0°C.)
- Storage temperature range: -5°C to 35°C. Avoid leaving the product in environments above 35°C for extended periods.

### Prohibited Actions:

- Do not place this product in fire or water.
- Do not wipe the product with a damp cloth to prevent electrical short circuits or malfunctions.
- Do not cover or obstruct the product with paper or other objects to ensure proper heat dissipation.
- Do not drop, vibrate, knock, impact, or squeeze the product forcefully.
- Do not short-circuit the cathode and anode to prevent fire.
- Do not disassemble the product, as it contains no user-serviceable parts.



## Safety and Usage Guidelines

### Usage Precautions:

- Always supervise the product while in use.
- Keep the product out of reach of children.
- Verify that the charger's output voltage matches the product to prevent damage or hazards.
- Use chargers from reputable manufacturers with national 3C certification.
- Unplug the charger promptly after the power bank is fully charged.

### Handling Abnormalities:

- If you notice any abnormal odor, heat, discoloration, deformation, or leakage, stop using the product immediately.
- If the skin comes into contact with battery liquid, rinse thoroughly with water and seek medical attention.

### General Guidelines:

- Do not use the product if it has been immersed in water.
- Avoid prolonged contact with the product's indicator light area (maximum contact time: 1 minute).
- Dispose of the product properly when no longer needed.
- During use, place the product on a flat surface. If contact with the human body is necessary, limit it to less than 10 seconds.

## ? FAQ

Malfunction	Reasons	Solutions
Indicators can't display charging fully after long time charging of the product	<ol style="list-style-type: none"> <li>1. Not enough charging time</li> <li>2. Adaptor or the product problem</li> </ol>	<ol style="list-style-type: none"> <li>1. Charging the product for 12 hours</li> <li>2. Consulting the distributor or aftersales services</li> </ol>
Can not detect the remaining power of the product	<ol style="list-style-type: none"> <li>1. No remaining power</li> <li>2. Power button or indicators problem</li> <li>3. The breakdown of the product</li> </ol>	<ol style="list-style-type: none"> <li>1. Recharging</li> <li>2. Consulting the distributor or aftersales services</li> </ol>
The product can't charge or supply power for other devices	<ol style="list-style-type: none"> <li>1. Low power of the product</li> <li>2. No power from USB cable or adaptor</li> <li>3. Improper choice for adaptor</li> <li>4. The power management system of the product prohibits the charging or supplying power</li> </ol>	<ol style="list-style-type: none"> <li>1. Recharging the product again</li> <li>2. Changing a USB cable or adaptor</li> <li>3. Looking for proper adaptors</li> <li>4. Not suitable for the devices of the product</li> </ol>
The product can charge or supply power for other devices but can't charge fully for them	No power	Recharging the product
When charging other devices with the remaining power, the product suddenly stops working and fails to show power	External short circuit or over load will lead to a automatic protection from the product itself	Recharging the product to reactivate





# **WARRANTY CERTIFICATE**

This document has been prepared by taking into account the principles of

WARRANTY CERTIFICATE of Consumer Protection Law No. 6502.

## WARRANTY CONDITIONS

- 1) Warranty period is 2 years from the delivery date of the goods.
- 2) All parts of the product are guaranteed.
- 3) If the goods are found to be defective, the consumer, 6502 Article 11 of the Law on Protection

**A-** Return from contract

**B-** Requesting discounts

**C-** Free repair request

**D-** May take the right to ask for the sale to be replaced with a non-defective product.

- 4) If the consumer chooses the right to free repair from these rights seller; It is obliged to make or repair the goods without any charge under the cost of labor, replacement parts or any other name.

The consumer can also use the right to free repair against the manufacturer or importer. Seller, manufacturer and importer are responsible for the consumer's right to use this right.

- 5) If the consumer uses the right of free repair,
  - Failure to repeat within the warranty period
  - Exceeding the maximum time required for repair
  - In cases where it is not possible to establish a report by authorized service station, dealer, manufacturer or importer; the seller can demand the return of the price of the goods, the price reduction at the price of shame or the replacement of the goods with the non-defective product if possible.

The seller cannot refuse the consumer's demand. If this request is not fulfilled, the seller, the manufacturer and the importer shall be jointly responsible.

**6)** The repair period of the goods can not exceed 20 working days. This period starts at the date of notification of the defect to the authorized service station or the seller within the warranty period and the date of delivery of the goods to the authorized service station.

If the defect, goods, manufacturer or importer is not repaired within 10 working days; Until the repair of the goods has been completed, it should allocate another product with features similar to consumer use. In case of malfunction of the goods within the warranty period, the time spent in the repair is added to the warranty period.

**7)** The use of the product contrary to the instructions in the manual is not covered by the warranty.

**8)** The consumer may apply to the Consumer Arbitration Committee or the Consumer Court at the place of settlement of the disputes that may arise in relation to the use of the rights arising from the warranty or in the place where the consumer transaction is made.

**9)** In the event that this Warranty Certificate is not provided by the Seller, the consumer may apply to the General Directorate of Consumer Protection and Market Surveillance of the Ministry of Customs and Trade.

**WARRANTY CERTIFICATE****Import company**

Title : **LİNK TRADING ELEKTRONİK SANAYİ VE TİCARET LİMİTED ŞİRKETİ**

Address : Süleymaniye Mah. Ord. Prof. Dr. Cemil Bırsel Cad. nezihbey İşhane No: 26  
İç Kapi No: 206 Fatih/ İstanbul

Phone Number : 0850 340 88 88

Fax :

Email : eticaret@linktech.com.tr

Signature of the official :

Company stamp :

**Sales brand**

Title :

Address :

Phone Number :

Fax :

Email :

Signature of the official :

Company stamp :

**Product**

Type:

Brand Name:

Model:

Warranty Period: 2 Years

Maximum Repair Time: 20 Business days

Bandrol and Serial No: